

INSTRUCTION MANUAL A

NAJI


art. 01-1452




www.redogroup.com

- IP44
- 01
- 02
- 05
- 08
- 17
- 18
- 21
- 24
- 31


1




2




3




4



5



6



INSTRUCTION MANUAL A

NAJI

art. 01-1453, 01-1454



www.redogroup.com

IP44



01




02



05



08



17



18

MAX
12W
18W

21




24




31

Redo
GROUP


1




2




3



4



5



6

