



KANT

Art. 91009, 91010, 91011, 91012
SMD LED, 3W




02



06



10



11



14




16



17



23




24



34




38




27

KANT

Art. 91013, 91014, 91015, 91016
SMD LED, 3W




02



06



10



11



12



16



18



23




24




34



39




27




31

KANT

Art. 91017, 91018, 91019, 91020
SMD LED, 4,5W




02



06




10



11



14




16



17



23




24



34




38




27

KANT

Art. 91021, 91022, 91023, 91024
SMD LED, 4,5W




02



06




10



11



12



16



18



23



24




34



39




27



31

KANT

Art. 91025, 91026, 91027, 91028
SMD LED, 15W



02



06



10



11



12



16



18



23




24




34



37



27




31

KANT

Art. 91029, 91030, 91031 - SMD LED, 15W

Art. 91035, 91036, 91037 - SMD LED, 15W



02



08



10



11



14




16



17



23




24



34



39




27


KANT

Art. 91032, 91033, 91034 - SMD LED, 15W

Art. 91038, 91039, 91040 - SMD LED, 15W



02



08



10



11



12



16



18



23




24




34



38



27



31